ALERT™ J5



ALERT J5

Professional breath alcohol tester and printer



Convenient menu

The ALERT J5 easily allows you to capture breath samples, print test results with the optional print function, and recall previous tests in seconds.

Active and passive sampling

Our customers requested and we've responded: the ALERT J5 now offers both passive and active testing capabilities. Whether a simple Pass/Warn/Fail or a precise numerical value is required, the ALERT J5 meets the demand.*

Evidential accuracy

The ALERT J5 uses a fuel cell – the standard in law enforcement breath testers - to detect breath alcohol. The long term stability of the sensor means you can count on accurate results year after year.

Test result printing

When breath sample evidence is required, the ALERT J5 offers Bluetooth and USB printing capabilities using the provided thermal printer. Recall any one of thousands of stored tests to print.

Multi-language display

Users can easily change languages without having to upgrade software. All ALERT J5 alcohol testers are available with multiple language options.**

Limited warranty

ACS breath alcohol testers are warranted to be free from defects in workmanship and material for one year from the date of purchase. Only qualified technicians should perform the maintenance of any breath alcohol tester.

Specifications

Size:	130 mm x 59 mm x 32 mm
Weight:	110 grams
Sensor:	Electrochemical
Specificity:	Alcohol only, no response to ketones or hydrocarbon
Operating temperature:	-20 to +65 °C
Purge cycle (initial test):	< 30 seconds
Breath sample:	5 second moderate and continuous breath sample
Analysis time:	< 10 seconds
Recycle (recovery) time:	10 seconds
BAC readout format:	mg/dL, g/dL, g/L, mg/L, μg/dL, μg/L
Range of measurement:	0.00 to 0.650 g/dL
Accuracy:	± 5% at 0.10 g/dL
Display:	Graphical LCD
Last test recall:	Yes
Battery:	Two AA alkaline
Number of tests:	> 1,000 tests
Mouthpiece:	95-000145
Complete package:	ALERT J5, batteries and 5 mouthpieces
Printer:	Thermal dot matrix
Calibration:	ALCOSIM™ or equivalent

ACS, ALCOHOL COUNTERMEASURE SYSTEMS, ALCOLOCK, ALCOSIM, ALERT and the "Molly" are trademarks of Alcohol Countermeasure Systems



Alcohol Countermeasure Systems Corp 60 International Boulevard Toronto, Ontario M9W6J2 CANADA

T +1 416 619 3500

F +1 416 619 3501 acs-corp.com

^{*} All breath alcohol testing devices require periodic maintenance and calibration to ensure proper working order.

^{**} Minimum order quantities apply.